



Glo Brite®

Issue Date: 1/1/2016 Version 1.2

## PREPARATION

1. Do not apply Glo Brite® if the surface temperature is below 50 degrees Fahrenheit.
2. Always apply Glo Brite® to a clean, dry, wax and oil-free surface.
3. Seal porous surfaces, fill all cracks and repair to a smooth finish.
4. Testing of adhesion to the surface should be done before starting installation.
5. Glo Brite® works by exposure to ambient light or natural sunlight. Fluorescent light exposure is the best and fastest charging light. However, incandescent light will work by simply taking longer to charge. There must be a minimum amount of ambient light for Glo Brite® to charge sufficiently.

## INSTALLATION

1. Peel off protective release paper and press Glo Brite® into place.
2. Using a rubber hand roller over tape may increase adhesive bond.
3. Glo Brite® is ready for immediate use.